



ConnectPro™

How to install an amplifier into your car or truck.



Before you get started, you're going to need a few tools to do the job:

- A. Philips-head screwdriver
- B. Drill



You will also need RCA cables long enough to run from your stereo to your new amp, as well as a new fuse and fuse box, power, ground and remote start cable, and mounting screws.

Once you've picked out your new amplifier, determine the best location for installation based on it's size.

Make sure the location you pick has proper ventilation and can be accessed easily for adjustments later.





ConnectPro™

How to install an amplifier into your car or truck.



Once you have your spot located to mount the amp, use the drill to screw the amp down securely.



If there is carpet, we would suggest using spacers to place under the unit for better ventilation, and a place to run the wires if desired.

Now you'll have to install the power cable.

Running cables under carpet and through the firewall will most likely include some basic disassembly.

Run the cable directly to your battery from your amp location.





ConnectProTM

How to install an amplifier into your car or truck.



Before you attach the cable to the battery, I would suggest you install an inline fuse about 12 inches away from the battery. As well, find or create a clean screw hole in the body of your car and ground out the amp there.



Once completed, remove the radio from the dashboard and make the proper connections at the back of the radio for signal and turn on, then reinstall the radio.